WIRELESS
MULTI-MEDIA
KEYBOARD
AND OPTICAL MOUSE SET

QUICK START GUIDE





Thank you for purchasing the MANHATTAN® Wireless Multi-Media Keyboard and Optical Mouse Set, Model 172554 (PS/2) or Model 175579 (USB).

Using 27 MHz RF wireless technology, this sleekly styled optical keyboard with mouse has a working range of up to 1.5 meters (approx. 5 feet) from the base receiver, providing secure, reliable performance for home, office, conference room and entertainment applications. Additional features include:


- 2 full-size shift keys, separate cursor/navigation controls and Power, Sleep and Wake management keys
- 12 hotkeys for quick, one-touch access to frequently used multi-media and Internet functions
- Ergonomic key layout with a generous work area and adjustable tilt mechanism for comfortable typing positions
- Lifetime Warranty

FCC Statement


This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

BATTERY INSTALLATION

The wireless keyboard and optical mouse each use two AA batteries. For optimal performance, alkaline batteries are recommended. Slide







open the battery compartments on the bottom of both the keyboard and the mouse, insert the batteries, then replace the compartment covers.

CONNECTING THE RECEIVER

The wireless keyboard and optical mouse use digital radio technology to communicate, transmitting RF signals that are picked up by the receiver and then passed to the computer. The receiver is connected to the computer's PS/2 ports (Model 172554) or USB ports (Model 175579) with a cable: the green connector to the mouse port; the purple connector to the keyboard port.

For optimal performance, place the receiver at least 20 cm (approx. 8 inches) away from any computer components, including monitors, as they can cause radio interference.

NOTE: This keyboard/mouse set is Plug and Play; that is, it needs no software installed. If any software was installed to operate previous keyboards or mice, remove the driver(s) before using this set.

CAUTION: Turn off the computer before connecting the receiver, and avoid placing the receiver on a metal surface, as this can reduce the RF performance.

SETTING THE ID CODES

After installing the batteries and connecting the receiver, turn on the computer. Press the ID button on the receiver (see images above), then



— using a straight pin or another suitable object — press the recessed ID button on the underside of the mouse.

Wait a few seconds, press the ID button on the keyboard, then press the ID button on the receiver a second time. The ID code will be set automatically.

The receiver LED blinks when the mouse is moved or keystrokes are entered, indicating the keyboard and mouse are communicating with the receiver. If the receiver LED is not blinking, check the batteries and repeat the steps above.

USING THE MOUSE

To scroll up, move the mouse's scroll wheel forward; to scroll down, move it backward.

To use the scroll wheel as a standard middle button, simply press (click) the wheel.

NOTE: The mouse enters a power-saving mode after eight minutes of inactivity. To wake up (re-activate) the mouse, press either of its buttons.

USING THE KEYBOARD

In addition to Power, Sleep and Wake, the wireless keyboard features 12 hotkeys that provide one-touch access to the following multi-media and Internet functions.

- Play/Pause for audio or video discs
- · Volume Up to increase the volume
- · Volume Down to decrease the volume
- Mute to suppress sound during disc play
- Prev Track to revert to the previous disc track
- Next Track to advance to the next disc track
- Stop to stop downloading Web page content
- Home to open an Internet Explorer browser
- Email to open Outlook Express
- Search to launch the Web search function
- Page Forward to revert to the previous Web page
- Page Back to advance to the next Web page



SPECIFICATIONS

General

- Multi-media keys (Prev Track, Next Track, Play/Pause, Stop, Volume Up, Volume Down and Mute)
- Internet keys (Page Forward, Page Back, Home, Email and Search)
- · Power, Sleep and Wake management keys
- · Compatibility:
 - Model 172554: Windows 98SE/Me/2000/XP/Vista
 - Model 175579: Windows Me/2000/XP/Vista

Electrical (working levels)

- Voltage: keyboard and mouse, 2.0 3.2 V; receiver, 4.5 5.5 V
- Current: keyboard, < 8 mA; mouse, < 30 mA; receiver, < 40 mA
- Frequency: 27 MHz

Physical

- Key cap force: 60 +/- 15 g; pulling force, 1.2 1.5 kg
- Switch life: keyboard, 10,000,000 keystrokes; mouse, 1,000,000 times
- · Mouse switch force: 60 +/- 15 g
- Keyboard: 48 x 18 x 4 cm (19 x 7 x 1.5 in.); Set, 925 g (33 oz.)
- Wireless optical mouse: 800 dpi resolution; 130 x 68 x 45 mm (5 x 3 x 2 in.); two-button
- Base: 105 x 78 x 27 mm (4 x 3 x 1 in.)

Environment

- Working temperature: -15 50°C; humidity, 10 85%
- Storage temperature: -15 60°C; humidity, < 90%

Package Contents

- · Wireless Multi-Media Keyboard and Optical Mouse Set
- Receiver base with cable: 1.5 m (5 ft.)
- · (4) AA batteries
- · Quick start guide and driver CD





www.manhattan-products.com

Are you completely satisfied with this product? Please contact your MANHATTAN® dealer with comments or questions.

Copyright @ MANHATTAN

All products mentioned are trademarks or registered trademarks of their respective owners.